



# ***DA* Dakota Alert, Inc.**

## **DCMT-2500 Wireless Transmitter**

**Owner's Manual**





## Warnings

This device complies with Part 15 of the FCC rules, Operation of this device is subject to the following conditions: 1. This device may not cause harmful interference. 2. This device must accept any interference, including interference that may cause undesired operation.

## Installation:

The DCMT-2500 transmitter is used with the Dakota Alert DCR-2500 receiver. The DCMT-2500 transmitter uses a passive infrared (PIR) detector to detect people, vehicles or large animals at the monitored location. When the transmitter detects an object, it will send a signal to the receiver, which will sound one of four different tones (Classical, Westminster Chime, Ding Dong, or Whistle) for a few seconds. The transmitter can be used as a driveway alarm, or in the back yard to monitor around tool sheds or patios.

## Operation: (Always test unit prior to installation)

1. Connect a 9-volt alkaline battery to the transmitter.
2. For maximum range between the transmitter and receiver, the transmitter should be mounted on a wooden post or tree (steel posts may cause interference with the radio signal). Although the maximum range is about a 1/2 mile, obstructions such as hills, trees, metal siding and stucco can reduce the range.

2.





### PIR settings (figure 1)

The jumpers settings are as follows:

- Range:** High- 80 feet  
Medium- 50 feet  
Low- 30 feet
- LED:** ON- led will flash when it detects  
OFF- led is always dark
- Filter:** On- set for outdoor use  
Off-set for indoor use
- Reset:** 15 seconds to reset after activation  
120 seconds to reset after activation

### Coding the transmitter:

**Note: The transmitters and receivers are preset at the factory. DO NOT change settings, unless changing the tune or experiencing false signals.**

1. When looking at the PIR you will see clips on the sides of the plastic case. Push one of the clips away from the center of the case and lift out the PIR and the plastic backing. You will now be looking inside of the case at the radio transmitter (figure 2).




Figure 1  
PIR with cover removed

3.



2. Locate the dip switches in the DCMT-2500 transmitter module (figure 2).
3. The first eight dip switches are for the frequency setting (256 combinations). Set switches 1-8 (3) to match the eight switches in the receiver.
4. Switches 9 and 10 (4) are for the zone/channel settings on the transmitter. The four zones are listed in the table below.

**LOW BATTERY ALERT:** If the receiver sounds a second alert 30 seconds after the first alert, provided nothing trips the transmitter again, the 9-volt battery in the transmitter should be changed.

Switch 9	Switch 10	Channel	Tune
On	On	1	Classical
Off	On	2	Westminster
On	Off	3	Ding Dong
Off	Off	4	Whistle




figure 2

4.



### Mounting the transmitter:

1. Select a location to mount the transmitter, such as a post or tree.
2. For best results, the transmitter should be about three to four feet off the ground, and about twenty feet from the side of the drive.
3. The transmitter will detect people or vehicles to about eighty feet, but occasionally it may detect one hundred feet. For this reason, it is best to avoid pointing the transmitter at streets or roads in the distance.
4. The transmitter must remain completely immobile or a false signal may result. For this reason, avoid mounting the transmitter on flimsy objects or small diameter trees that may move in the wind




figure 3

5.





### **Coding the receiver:**

1. Open the receiver case by inserting a small screwdriver into one of the pry notches on the side of the case. (refer to receiver manual)
2. Gently lift off the front cover.
3. Locate the eight dip switches on the receiver and make sure they are set identically to dip switches 1-8 on the transmitter.

***Note: If more than one transmitter is used with the receiver, the first eight dip switches of all transmitters must match the eight dip switches of the receiver.***

***Note: Whenever a change is made to the time jumper or the dip switches, the receiver must be turned OFF and then back ON to operate properly.***

Frequency: 433.92 MHz

Operating range: -30°F to 110°F

Battery life: 6-12 months

6.





## Troubleshooting the DCMT-2500

Although the DCMT-2500 should be very reliable, there are occasions when you might have false alarms or a failure to alert. If you are getting false alarms, please try this:

- Set filter jumper to “ON”.
  - Decrease range jumper.
  - Make sure that the transmitter is not pointing at a road in the distance.
  - The sun may be causing false signals; try to relocate the transmitter to a different position.
  - Make sure the transmitter is not detecting animals.

If the transmitter is not detecting, try one of these:

- Change the battery in the transmitter.
- Make sure the transmitter and receiver are coded alike.
- Change the height and distance of the transmitter from the driveway.
- Move the transmitter closer to the receiver.
- Keep the transmitter away from large metal objects that may interfere with the radio signal.

## TECHNICAL SUPPORT

If you encounter any difficulty in the operation of this product after reading the manual, please contact us. You can reach us by phone at 605-356-2772 from 8:30 AM to 5:00 PM Monday through Friday (Central Standard Time). We will be happy to answer your questions and help you in any way we can.





## **WARRANTY**

Dakota Alert warrants this product to be free of defects in material and workmanship for a period of one year from the date of purchase. This warranty does not cover damage resulting from accident, abuse, act of God or improper operation.

If this product does become defective, simply return it to Dakota Alert. Please include a note describing the troubles along with your name and return address as well as the original sales receipt. If the product is covered under warranty it will be repaired or replaced at no charge. If it is not covered by warranty, you will be notified of any charges before work is done.

## **Dakota Alert, Inc.**

32556 E. Main Street  
PO Box 130  
Elk Point, SD 57025

Phone: (605) 356-2772

Fax: (605) 356-3662

Web: [www.dakotaalert.com](http://www.dakotaalert.com)

8.

